

# PACIFIC LIGHT

## WELCOME

### 1.0 INSTALLATION

- 1.1 Tools
- 1.2 Installation Options
- 1.3 Points to Consider before Installation
  - 1.3.1 Positioning the System
  - 1.3.2 Bad Air and the Windvane
  - 1.3.3 Pendulum Rudder and Main Rudder
  - 1.3.4 On Land or in the Water?
- 1.4 Installation: Quick Guide
  - 1.4.1 The Five Criteria
- 1.5 Installation: Comprehensive Guide
  - 1.5.1 Height above the Waterline
  - 1.5.2 Do I Need to Reinforce the Transom?
  - 1.5.3 What if the Bracket is Aligned Incorrectly?
  - 1.5.4 Mounting the System on the Mounting Bracket
  - 1.5.5 Alignment
  - 1.5.6 Pendulum Rudder Lift-up
- 1.6 The Steering Lines
  - 1.6.1 General
  - 1.6.2 The Basics
  - 1.6.3 WINDPILOT System Requirements
  - 1.6.4 Crossbar
  - 1.6.5 Dedicated Break Point for Steering Lines
  - 1.6.6 Should I Splice the Steering Lines?
  - 1.6.7 Steering Lines and Tiller Steering
    - 1.6.7.1 Positioning the Tiller Fitting
    - 1.6.7.2 Positioning the Ring on the Pendulum Arm
    - 1.6.7.3 Steering Line Blocks
    - 1.6.7.4 Line Tension
    - 1.6.7.5 Centring the Tiller and the Chain
  - 1.6.8 Steering Lines and Wheel Steering
    - 1.6.8.1 Fitting the Wheel Adaptor
    - 1.6.8.2 Rigging the Steering Lines
    - 1.6.8.3 Connection Point
    - 1.6.8.4 Line Tension
    - 1.6.8.5 Transmission Ratio
    - 1.6.8.6 Variable Force Transmission
    - 1.6.8.7 Force Transmission with Wheel Steering:  
Examples
  - 1.6.9 Steering Lines and the Emergency Tiller
    - 1.6.9.1 Mechanical Wheel Steering
    - 1.6.9.2 Hydraulic Wheel Steering
- 1.7 The Pendulum Rudder
  - 1.7.1 Mounting the Rudder Blade
  - 1.7.2 Positioning the Rudder Blade
  - 1.7.3 Overload Protection

1.7.4 Pendulum Rudder Lift-up  
1.8 WINDPILOT and Autopilot

2.0 SAILING WITH YOUR WINDPILOT

- 2.1 Sailing with Your Windpilot: Quick Guide
- 2.2 Sailing with Your Windpilot: Comprehensive Guide
  - 2.2.1 System Not in Use
  - 2.2.2 Preparing for Use
  - 2.2.3 Connecting the Steering Lines
    - 2.2.3.1 Tiller
    - 2.2.3.2 Wheel
  - 2.2.4 Altering Course/Turning
  - 2.2.5 Fine Trim - Tiller Steering
  - 2.2.6 Fine Trim - Wheel Steering
    - 2.2.6.1 Is the Variable Force Transmission Set Correctly?
    - 2.2.6.2 Determining the Ideal Settings
  - 2.2.7 Setting the Windvane for Different Wind Strengths
    - 2.2.7.1 Light Winds
    - 2.2.7.2 Moderate Winds
    - 2.2.7.3 Strong Winds
    - 2.2.7.4 The Ideal Windvane Position
  - 2.2.8 Switching Back to Manual Steering
    - 2.2.8.1 Emergency
    - 2.2.8.2 Normal Use
  - 2.2.9 Removing the System in Harbour/for Winter Storage

3.0 CAUTION

4.0 MAINTENANCE

- 4.1 Bearings
- 4.2 Cleaning
- 4.3 Bevel Gear Linkage
- 4.4 Push Rod
- 4.5 Cast and Tubular Components
- 4.6 Lanolin
- 4.7 Antifouling
- 4.8 Windvane
- 4.9 Windvane Telltale

5.0 TROUBLESHOOTING

- 5.1 System is Turning the Wrong Way
- 5.2 System Performance is Not Satisfactory
  - 5.2.1 Position of Pendulum Rudder Blade
  - 5.2.2 Steering Lines Rigged Incorrectly
  - 5.2.3 The Pendulum Rudder is Not Moving 25 Degrees to Each Side
- 5.3 System is Sticking
  - 5.3.1 At the Windvane
  - 5.3.2 At the Windvane Shaft

5.3.3 At the Rudder Axle

5.3.3.1 Disassembly Procedure

5.3.3.2 Reassembly Procedure

5.3.4 At the Steering Lines

5.4 The Push Rod is Bent

5.5 The Windvane Shaft is Loose

5.6 The Rudder Blade is Vibrating

6.0 REPAIRS

WELCOME ...

... to the world of silent self-steering!

Prepare to be pleasantly surprised by your new windvane steering system: life aboard will never be the same again!

Learn to trust your new live-aboard guest. Enjoy the moment you realise it can steer with the kind of stamina and prolonged precision we can only dream of. Hand over to your tireless new mate and make the most of all the time it leaves you for other things. Life aboard will become much more relaxed; time at sea will be generally more restful. And those long trips that were once all but inconceivable are now very much within your grasp.

We at WINDPILOT are almost as single-minded as our windvane gears. We have been continuously developing and refining our systems for more than 30 years now - and all that experience comes free with every system sold. You will notice the difference: we have left no stone unturned!

KISS (keep it simple, stupid) - that's the motto we live by at WINDPILOT. We realise that manuals are probably well down your list of reading priorities, but there are mistakes to be made and they can be avoided. Good advice is particularly valuable at sea, especially if you have it there on board with you, so take a deep breath and read on...

You expect good steering from your WINDPILOT and it, in turn, has certain expectations of you:

**- DON'T NEGLECT YOUR SAIL TRIM**

Poor trim amplifies weather helm, which means more pressure on the rudder and less boat speed. Don't sail with the handbrake on! A well trimmed boat heels less and requires less pressure on the rudder. That means it sails faster. Adjust the mast, trim the sails: try it, you have plenty of time!

**- BE AWARE OF THE CONDITIONS**

Some combinations of wind and sea conditions will be too much for your windvane gear: imagine trying to steer around breaking waves with your eyes closed, for example.

**- MAKE SURE YOUR WINDPILOT IS PROPERLY INSTALLED**

Install it with care, treat it well and be prepared to give it a little attention now and again.

**- TALK TO US, PREFERABLY RIGHT FROM THE START**

If you would like confirmation that your system is properly installed and that the steering lines and so on are just right, send us a few photos of your WINDPILOT set up and ready for action. Pictures tell it like it is and make it easier for us to help you.

You have our word on it - lazy days at sea await... at least as far as steering is concerned...

Peter Förthmann

## PACIFIC LIGHT

### 1.0 INSTALLATION

#### 1.1 TOOLS

- ~ rule
- ~ pencil
- ~ 2.5 mm and 5 mm Allen keys (included in delivery package)
- ~ 9 mm and 10.5 mm drill bits
- ~ 10 mm, 17 mm and 19 mm ring/fork wrench/spanner
- ~ Sikaflex sealing compound
- ~ rubber mallet
- ~ drill

#### 1.2 INSTALLATION OPTIONS

- 3 Abb ML 0 = standard mounting bracket for moderately raked sterns  
 ML 1 = mounting bracket with extension for extreme sterns  
 CB = crossbar for steering lines on extreme sterns  
 WC = wheel adaptor for boats with wheel steering

#### 1.3 POINTS TO CONSIDER BEFORE INSTALLATION

The PACIFIC LIGHT was fully assembled before leaving our premises.

##### 1.3.1 POSITIONING THE SYSTEM

- Abb ~ Your WINDPILOT should be installed at the centre of the transom approximately 10 cm/4 in below deck level.
- ~ Off-centre installation is possible (max. 10 cm/4 in) but not ideal.
- ~ If your boat has a centrally mounted bathing ladder, it should be relocated to the port side.
- ~ **CAUTION:** think twice before moving the ladder to the starboard side. When the pendulum rudder is raised, the pendulum arm 300 swings down very close to the bottom of the transom on the starboard side - check for clearance.
- ~ **TIP:** install the PACIFIC LIGHT first, then sort out the bathing ladder.
- ~ Tie safety lines to all components before you start.
- ~ Secure clamps 860 on the mounting bracket with tape.
- ~ Coat the mounting bolts with lanolin or Duralac.
- ~ Should I use a spirit level? No, boats are never perfectly level; it is better to trust your eye.

##### 1.3.2 BAD AIR AND THE WINDVANE

- ~ The windvane should not be subject to disturbed airflows in its working position.
- ~ **NO PROBLEM**
- ~ Bad air from a sprayhood: the sprayhood is normally far enough from the stern not to be a problem.
- ~ Bad air around davits
- ~ Bad air from the superstructure
- ~ Bad air off the mainsail (sloop/cutter)
- ~ Bad air caused by people in the cockpit

## PROBLEM

- ~ Bad air off the mizzen sail
- ~ Bad air caused by an outboard motor on the pushpit
- ~ Bad air caused by fenders/liferaft on the pushpit

### 1.3.3 PENDULUM RUDDER AND MAIN RUDDER

- ~ The pendulum rudder is used simply to generate hydrodynamic force; since it does not steer the boat directly, is ok for it to be close behind the trailing edge of the main rudder.
- ~ The pendulum rudder moves laterally in operation.
- ~ Turbulence caused by the main rudder does not interfere with the operation of the pendulum rudder.

### 1.3.4 ON LAND OR IN THE WATER?

- ~ You can fit your WINDPILOT with the boat ashore or afloat: it doesn't really matter, as all the holes are above the waterline.
- ~ But the height above the waterline for installation is easier to find with the boat in the water.

## 1.4 INSTALLATION: QUICK GUIDE

### 1.4.1 THE FIVE CRITERIA

- Abb mit 5  
Kreis-en
- 1 - Installation height: mounting bolt 430 for the pendulum rudder blade 440 should be 5-10 cm/2-4 in above the water (static waterline).
  - 2 - Overhanging/traditional sterns: does ring 315 on the pendulum arm 300 swing clear of the top of the transom/pushpit when the pendulum rudder is raised?
  - 3 - Forward-raked/sugar-scoop sterns: does pendulum rudder shaft 400 swing clear of the bottom/aftermost edge of the transom?
  - 4 - Start by fastening the mounting bracket in place with just one bolt. Then align the bracket, mark where the remaining holes should be and predrill them with the 9 mm bit. Now drill out the holes with the 10.5 mm bit and complete installation of the mounting bracket.
  - 5 - Align the system. Windvane shaft 140 must be vertical!

## 1.5 INSTALLATION: COMPREHENSIVE GUIDE

- foto  
Hammer
- ~ Remember the five criteria.

### 1.5.1 HEIGHT ABOVE THE WATERLINE

- ~ The rudder shaft has been manufactured to the correct length for your boat.
- ~ The dynamic waterline should cover the rudder blade.
- ~ The rudder will project some distance above the static waterline.
- ~ Ideal installation height: bolt 435 should be about 5-10 cm/2-4 in above the static waterline.
- ~ Locate the mounting bracket on the transom at the appropriate installation height.
- ~ Use the mallet to rotate the four clamps 860 into place against the transom.
- ~ Drill one hole (predrill with the 9 mm bit then complete with the 10.5 mm bit).

~ Pass a bolt through the hole just drilled to hold the bracket in place.  
 ~ Align the bracket (level).  
 ~ Predrill the remaining three holes through the clamps (9 mm bit).  
 ~ Remove the bracket.  
 ~ Drill out all the holes with the 10.5 mm bit.  
 ~ Place sealing compound (Sikaflex) around each hole.  
 ~ Set the 60 mm diameter plastic discs on the Sikaflex compound.  
 ~ Fasten the bracket with all four bolts.  
 ~ Working inside the hull, set the washers on the bolt ends and tighten the nuts/locknuts.  
 ~ SEQUENCE: bolt head/stainless washer/plastic washer/clamp/60 mm plastic disc/Sikaflex/transom/stainless washer/nut/nut

~ CAUTION: The bolts must be properly seated and tightened - check them regularly!

~ If the bolts work loose, the whole system could be lost.

~ Attach a safety line to your PACIFIC LIGHT just in case.

#### 1.5.2 DO I NEED TO REINFORCE THE TRANSOM?

~ No. The forces on the transom are relatively low and should never exceed the steering force exerted on the tiller plus the weight of the system itself.

#### 1.5.3 WHAT IF THE BRACKET IS ALIGNED INCORRECTLY?

~ No problem: loosen mounting bolts 901 and use the rubber mallet to move the clamps along the cheeks 900/910 until the alignment is satisfactory.

#### 1.5.4 MOUNTING THE SYSTEM ON THE MOUNTING BRACKET

~ Slide the system into the bracket with the pendulum axle 310 at the front and fasten in place with mounting bolt 901.

#### 1.5.5 ALIGNMENT

##### WINDVANE SHAFT 140

~ The windvane shaft 140 must be vertical.

~ Side-to-side adjustment: release bolt 701

~ Fore-and-aft adjustment: release bolt 201

~ Don't forget to retighten the bolts once the windvane is properly aligned!

~ If you still can't make the windvane vertical, see 1.5.4 What if the Bracket is Aligned Incorrectly?

#### 1.5.6 PENDULUM RUDDER LIFT-UP

~ Tie one end of the red lift-up line through ring 431 and secure the other end to the pushpit. Raise the pendulum rudder, take the red line once around windvane shaft 140 and rudder shaft 400 and tie it back to the pushpit.

### 1.6 THE STEERING LINES

#### 1.6.1 GENERAL

Abb

foto

The steering performance of your PACIFIC LIGHT will be strongly influenced by the quality of the force transmission from the pendulum rudder to the main rudder; in other words, you can't have good steering unless the steering lines are working smoothly.

foto Aries Depending on the setting of the variable transmission, the PACIFIC LIGHT provides maximum steering line travel of between 20 and 25 cm/8 and 10 in (a feature it shares with other popular systems like the Aries and Monitor).

Anything that impairs the force transmission will have an immediate impact on steering quality. Slack, stretch or play in the steering lines or stiffness in the main rudder bearings all detract from the performance of your system. Errors and compromises at this point add up to poor steering, plain and simple. All servo-pendulum gears that use the 2:1 bevel gear linkage (Aries, Fleming, Monitor) work in exactly the same way. The differences lie in the operating conditions on different boats!

NOTE: what use is 20-25 cm/8-10 in of travel at the pendulum arm if only a fraction of that reaches the main rudder?

### 1.6.2 THE BASICS

foto Keep the steering lines as short as possible.

Hanseat Use the smallest possible number of blocks.

kockpit Use non-stretch lines.

Make sure the angle formed by the lines between the system and the back of the boat (seen from above) is no greater than 30 degrees.

Check the tension of the steering lines.

Watch to make sure that line travel is not being wasted between the pendulum arm and the main rudder.

Check that the main rudder bearings run smoothly.

Check wheel steering systems for play and stiffness.

### 1.6.3 WINDPILOT SYSTEM REQUIREMENTS

Abb Ring 315 on the pendulum arm must be at deck level.

This keeps the steering lines short.

There are no unnecessary blocks on the steering lines.

There are no blocks fitted to the system itself.

Foto Kegell- The pendulum rudder shaft is long enough to provide plenty of leverage for the  
rad/  
Buch pendulum rudder.

The bevel gear linkage is working properly to provide automatic yaw damping.

The system is sensitive in light airs but powerful in stronger wind conditions.

### CAUTION

Take care when setting up the steering lines between the WINDPILOT and the main rudder. Poor force transmission will seriously impair steering quality.

### 1.6.4 CROSSBAR

foto Quer- If the angle formed by the lines between the system and the first set of turning  
stange blocks on the back of the boat (seen from above) is greater than 30 degrees, performance is likely to suffer. The blocks may be moved to the ends of a crossbar fitted adjacent to the top of the mounting bracket to improve the angle and resolve the problem.



### 1.6.5 DEDICATED BREAK POINT FOR STEERING LINES

Two of the turning blocks for the steering lines should be fastened to the boat only with thin cord (e.g. 3 mm burgee halyard). If, for whatever reason, the transmission system should be overloaded, these lines will break and save the rest of the setup.

### 1.6.6 SHOULD I SPLICE THE STEERING LINES?

No, it is better just to use knots as you can then end-for-end the lines easily to spread the wear.

### 1.6.7 STEERING LINES AND TILLER STEERING

#### 1.6.7.1 POSITIONING THE TILLER FITTING

foto  
Pinnen-  
beschlag

Tiller fitting 010 should be mounted about 65% of the way along the tiller, measuring from the rear (e.g. if your tiller is 100 cm/40 in long, the fitting should be about 65 cm/26 in from the aft end).

Moving the tiller fitting further forward increases leverage but reduces the angle through which your PACIFIC LIGHT can turn the rudder.

Moving the tiller fitting aft increases this angle but reduces leverage.

NOTE: it is impossible to have more leverage AND more movement at the same time!

A servo-pendulum system with automatic yaw damping like the PACIFIC LIGHT is designed to operate with an average steering line travel between the system and main rudder of 20-25 cm/8-10 in.

#### 1.6.7.2 POSITIONING THE RING ON THE PENDULUM ARM

foto  
Barteis

Moving the ring up the arm (away from the axle) increases travel but reduces transmission force.

Moving the ring down the arm (towards the axle) increases transmission force but reduces travel.

See 2.2.6.2 Determining the Ideal Settings.

#### 1.6.7.3 STEERING LINE BLOCKS

The first pair of blocks should be mounted on or outside the pushpit as far aft as possible.

The other pair should be mounted on the cockpit coaming slightly aft of the tiller fitting.

Tie the steering lines to the ring 315 on the pendulum arm.

Lead them forward to the tiller through the two sets of blocks.

Attach the chain section where the steering lines approach the tiller fitting.

#### 1.6.7.4 LINE TENSION

The lines must be neither too slack nor too tight; either will impair steering.

The steering lines should be rigged such that engaging the chain in the tiller fitting sets them to their ideal working tension.

IDEAL TENSION: no slack, no strain.

### 1.6.7.5 CENTRING THE TILLER AND THE CHAIN

Abb ~ The system and tiller can be centred with respect to each other (e.g. to compensate for weather helm as wind and sea conditions change) by adjusting the chain at the tiller fitting.

~ Assembly sequence: line/shackle/chain/2 snap shackles/line.

### 1.6.8 STEERING LINES AND WHEEL STEERING

#### 1.6.8.1 FITTING THE WHEEL ADAPTOR

foto ~ Start by fastening the adaptor to one spoke of the wheel.

Rad- ~ Make sure the adaptor is centred and then fasten two more clamps to the wheel.

adap- ~ Remove the plastic retaining bolt. The adaptor must be able to rotate freely without fouling the spokes.

Abb neu ~ The lines should each be led around the adaptor one and a half times from the point where they attach to it (friction/load distribution). They can then be connected to the steering lines coming from the side/aft (using snap shackles).

#### 1.6.8.2 RIGGING THE STEERING LINES

foto ~ Both lines should initially be led from the ring 315 to the corners of the pushpit.

radüber- ~ If desired, one line may now be led across the pushpit so that both lines are on the same side of the boat.

tragung ~ NOTE: keeping both lines on the same side of the cockpit leaves the other side free for access.

~ Take the lines forward until they are level with the wheel.

~ Pass them through a pair of turning blocks and across towards the binnacle.

#### BOTH LINES ON THE PORT SIDE

~ The line that runs from the system to the port side of the boat should be led around the bottom of the wheel adaptor.

#### BOTH LINES ON THE STARBOARD SIDE

~ The line that runs from the system to the starboard side of the boat should be led around the bottom of the wheel adaptor.

#### 1.6.8.3 CONNECTION POINT

foto ~ Each line from the wheel adaptor should be connected to the appropriate steering line from the system using two snap shackles (i.e. four snap shackles in total).

~ This helps when you come to release or reconnect the lines (to engage or disengage the PACIFIC LIGHT). Ideally the connection should be half way between the binnacle and the pair of turning blocks at the side of the cockpit, but if there is insufficient space, the snap shackles can also be connected between the turning blocks in the cockpit and those on the pushpit.

~ CAUTION: be sure to mark the snap shackles so that you can tell which to connect to which!

#### 1.6.8.4 LINE TENSION

foto ~ Slack can be controlled by including an extra block on the steering lines. This span-nung block is mounted (e.g. on the pushpit) so that it can be tensioned perpendicular to

the lines using thin cord. The more you tension the cord, the more the block pulls the slack out of the steering lines.

~ Releasing this block provides sufficient slack to uncouple the snap shackles at the connection point.

~ The block can then be used to re-tension the steering lines once the snap shackles have been reconnected prior to switching over to WINDPILOT steering.

#### 1.6.8.5 TRANSMISSION RATIO

~ The wheel adaptor is designed for mechanical wheel steering systems with a range of around two and a half revolutions from stop to stop and a wheel diameter of approximately 60 cm/24 in. This means in practical terms that the maximum line travel of 25 cm/10 in is sufficient to turn the wheel through half a revolution given, perfect transmission.

#### 1.6.8.6 VARIABLE FORCE TRANSMISSION

~ The force transmission characteristics can be adjusted using the slot in the pendulum arm 300 (see 2.2.6.2 Determining the Ideal Settings).

#### 1.6.8.7 FORCE TRANSMISSION WITH WHEEL STEERING: EXAMPLES

Example 1:

foto

~ Wheel diameter = approx. 60 cm/24 in

~ Revolutions from stop to stop = 2.5

~ Position of ring 315 = approx. centred in the slot

Example 2:

foto

~ Wheel diameter = approx. 100 cm/40 in

~ Revolutions from stop to stop = 1.5

~ Position of ring 315 = towards the bottom of the slot

Example 3:

foto

holzrad

~ Wheel diameter = approx. 55 cm/22 in

~ Revolutions from stop to stop = 3-4

~ Position of ring 315 = towards the top of the slot

#### TEST

~ It is actually quite straightforward to work out the key parameters for your boat - see 2.2.6.2 Determining the Ideal Settings.

### 1.6.9 STEERING LINES AND THE EMERGENCY TILLER

#### 1.6.9.1 MECHANICAL WHEEL STEERING

~ Connecting the steering lines to the emergency tiller of a mechanical wheel steering system will not yield good steering because the tiller has to move the whole of the steering mechanism from the wrong end every time it tries to turn the rudder. It's like trying to turn the steering wheel of your car by sitting in the road and tugging on the front wheels!

~ Good steering can only be had by this route if the transmission components of the wheel steering system are completely disconnected from the quadrant (emergency).

#### 1.6.9.2 HYDRAULIC WHEEL STEERING

Connecting the steering lines to the emergency tiller of a hydraulic steering system is pointless, as the tiller cannot possibly supply enough force effectively to move the hydraulic cylinder. A bypass valve will not help either.

Good steering can only be had by this route if the transmission components of the wheel steering system are completely disconnected from the quadrant (emergency). A word of advice for anybody still tempted to try connecting a servo-pendulum system up to a hydraulically operated main rudder: don't do it - you'll end up steering by hand!

Hydraulic steering systems are in any case very rare on smaller boats.

## 1.7 THE PENDULUM RUDDER

### 1.7.1 MOUNTING THE RUDDER BLADE

foto  
holz

The pendulum rudder blade 440 should be mounted with the rounded edge facing forward and the sharp edge facing aft.

### 1.7.2 POSITIONING THE RUDDER BLADE

abb flucht-  
linie

The pendulum rudder blade must be angled down and aft exactly in line with the rudder shaft, otherwise the balance will be off.

Adjusting the rudder blade aft reduces the force generated (by reducing the balance proportion).

Adjusting the rudder blade forward increases the balance proportion excessively, with the result that the rudder controls the windvane instead of the other way around.

Both the adjustments described impair the performance of the system and make steering problems inevitable.

### 1.7.3 OVERLOAD PROTECTION

foto

Mounting bolt 435 for the rudder blade 440 should be tightened gently so that the rudder blade can still swing up if it strikes something below the water.

The rudder blade is retained in the shaft fork by friction only.

### 1.7.4 PENDULUM RUDDER LIFT-UP

foto

Tie one end of the red lift-up line through ring 431 and secure the other end to the pushpit.

Raise the pendulum rudder, take the red line once around the windvane shaft 140 and rudder shaft 400 and tie it back to the pushpit.

It is not possible to raise the pendulum rudder out of the water while the boat is moving as the resistance is generally too high. Lift-up under way may be possible at speeds below two knots.

The pendulum rudder may be dropped back into the operating position at any time.

## 1.8 WINDPILOT AND AUTOPILOT

The PACIFIC LIGHT is used exclusively on smaller boats, most of which will have tiller steering. If a cockpit autopilot is used, it should be connected as usual

to the main steering and not to the PACIFIC LIGHT. The autopilot is normally used when motoring, so there should be no problem with power consumption.

## 2.0 SAILING WITH YOUR WINDPILOT

### 2.1 SAILING WITH YOUR WINDPILOT: QUICK GUIDE

- ~ Bring the boat onto course.
- ~ Lower the pendulum rudder blade into the water.
- ~ Fit the windvane.
- ~ Set the windvane into the wind (it should now be standing upright).
- ~ Connect the steering lines to the boat's main steering.
- ~ Fine trim the steering at the system or the main rudder.

### 2.2 SAILING WITH YOUR WINDPILOT: COMPREHENSIVE GUIDE

#### 2.2.1 SYSTEM NOT IN USE

- foto  
nochmal mit  
gaggl
- ~ Keep the pendulum rudder blade in the lift-up position.
  - ~ Remove the windvane.

#### 2.2.2 PREPARING FOR USE

- ~ Bring the boat onto course.
- ~ Lower the pendulum rudder blade into the water.
- ~ Fit the windvane and turn it into the wind manually (the windvane should now be standing upright).
- ~ NOTE: the counterweight should now be pointing into the wind.

#### 2.2.3 CONNECTING THE STEERING LINES

##### 2.2.3.1 TILLER STEERING

- foto
- ~ Connect the two snap shackles.
  - ~ Engage the chain in the tiller fitting.
  - ~ Remove any slack in the lines.
  - ~ CAUTION: only remove the slack. Do not pull the lines taught, as this increases friction and impairs steering.

##### 2.2.3.2 WHEEL STEERING

- foto
- ~ Connect the two pairs of snap shackles (make sure the lines are not crossed!).
  - ~ Remove any slack in the lines.
  - ~ CAUTION: only remove the slack. Do not pull the lines taught, as this increases friction and impairs steering.

#### 2.2.4 ALTERING COURSE/TURNING

- foto  
Kai
- ~ Turn the windvane shaft 140 manually and refer to the degree scale on the windvane shaft.

#### 2.2.5 FINE TRIM - TILLER STEERING

- ~ If wind/weather helm change, adjust the rudder position by changing the chain link in the tiller fitting.

The windvane should work evenly around the upright position most of the time. If it is permanently off to one side, adjust your sail trim or reef down.

NOTE: your PACIFIC LIGHT can exert up to 200 kg/440 lbs of tensile force on the main steering, but sailing with the rudder well over all the time is highly undesirable (i.e. slow). Trim your boat and your sails - it's simpler and you'll get there faster!

You can tell if your trim could/should be improved just by looking at the tiller. If the tiller is constantly off-centre, something needs to be done!

### 2.2.6 FINE TRIM - WHEEL STEERING

Release the levers on the wheel adaptor.

Adjust the main wheel until the boat is properly balanced.

Retighten the levers.

CAUTION: do not overtighten the adaptor levers. The adaptor works like a disc brake: if the system is overloaded, the drum slides on the disc to absorb the excess force and prevent damage to itself or the other transmission components.

TIP: it is not necessary to release the adaptor levers completely to fine trim at the wheel. The whole operation is easier if they are simply loosened enough to allow the adaptor to slide. It is normally sufficient on a small boat to tighten only one of the levers. The second lever can then be tightened if required in more difficult conditions.

foto fest-  
steller

#### 2.2.6.1 IS THE VARIABLE FORCE TRANSMISSION SET CORRECTLY?

With the boat making good speed, manually turn the windvane all the way to one side and hold it there:

If the pendulum rudder moves approx. 25 degrees to one side, the force transmission is set correctly.

If the pendulum rudder moves significantly less than 25 degrees, slide ring 315 a little further down the pendulum arm (less travel but more force).

If you have tiller steering, you could alternatively move the tiller fitting forward (never move the fitting aft).

foto ring  
mutter

#### 2.2.6.2 DETERMINING THE IDEAL SETTINGS

The pendulum arm should always be able to make use of its full 25 degrees of travel to each side. This can be adjusted by moving the transmission point (ring 315).

TIP: leave the ring in the centre of the slot until you have tested everything properly under sail.

If the pendulum arm reaches 25 degrees off-centre too quickly and easily, move ring 315 up the slot (longer lever).

Keep testing the settings and moving the ring up until the lateral travel of the pendulum arm begins to be limited to less than 25 degrees.

Now gradually move the ring back down the slot, testing the different settings as you go, until the pendulum arm is just able to reach the full 25 degrees of travel.

CAUTION: larger, heavier boats may need to reach a relatively high boat speed to move the pendulum arm through the full 25 degrees.

The force generated by the servo system is always dependent on leverage, rudder area and speed. These factors are the product of physical laws, the consequences of which are inescapable!

Abb  
langloch  
mitte

oben

unten

## 2.2.7 SETTING THE WINDVANE FOR DIFFERENT WIND STRENGTHS

### 2.2.7.1 LIGHT WINDS

- foto wind-  
fahne  
telltale
- ~ Set the windvane absolutely vertical for maximum sensitivity.
  - ~ The upright setting also provides maximum steering force with the wind from astern.
  - ~ A strip of spinnaker cloth ('windvane telltale') on the upper trailing edge of the vane further improves sensitivity.
  - ~ CAUTION: you should not need to use a larger windvane in light airs. If you do use a larger vane, it must be exactly the same weight as the standard vane.
  - ~ This setting is particularly suitable for sailing with the wind aft of the beam, when the apparent wind strength is always relatively low.

### 2.2.7.2 MODERATE WINDS

- foto
- ~ Set the windvane angled back 20 degrees away from the wind.
  - ~ This position is the general setting for sailing with the wind forward of the beam (relatively high apparent winds).

### 2.2.7.3 STRONG WINDS

- Abb
- ~ Angle the windvane further back from the wind (more damping).
  - ~ If the windvane begins to vibrate in very strong winds, try angling it back even further. The vane can go as far as about 70 degrees back, which should improve damping and give smoother steering impulses (and hence better steering).
  - ~ This position is the general heavy air setting.

### 2.2.7.4 THE IDEAL WINDVANE POSITION

- foto wf  
schaft und  
fest-steller
- ~ The windvane should always be working evenly around the upright position.
  - ~ If all the movement is occurring on one side, i.e. between the upright position and one of the end stops, adjust the tiller connection or wheel adaptor position until the movement is more evenly distributed.
  - ~ If the windvane is permanently well over to one side, correct the course setting at the windvane shaft.
  - ~ Check the degree scale.
  - ~ NOTE: the reading on the scale at the windvane shaft 140 may differ slightly from the reading on your wind instrument. This is because wind conditions at deck level tend to be different from those at the top of the mast.

## 2.2.8 SWITCHING BACK TO MANUAL STEERING

### 2.2.8.1 EMERGENCY

- ~ Disconnect the steering lines from the main steering (tiller: disengage chain, wheel: release wheel adaptor adjustment levers).
- ~ The windvane gear is now completely isolated and will not interfere with the steering in any way. You may alter course as desired.

### 2.2.8.2 NORMAL USE

- ~ Remove the windvane.
- ~ Disconnect the steering lines from the main steering.

~ Lift up the pendulum rudder using the red line.

~ CAUTION: slow down before attempting to lift up the pendulum rudder. If the boat is moving too fast, there will be too much resistance to raise the pendulum rudder.

~ The pendulum rudder may actually be left in the water without doing any harm, but don't forget to lift it up out of the way before entering harbour/manoeuvring under engine.

### 2.2.9 REMOVING THE SYSTEM IN HARBOUR/FOR WINTER STORAGE

~ Release bolt ...

~ Secure the system with a safety line.

~ Remove the system.

~ There is no need to remove the mounting bracket.

~ CAUTION: When fitting/removing your PACIFIC LIGHT be sure never to handle/lift it by the windvane shaft 140 alone. The shaft is retained by just a single locking screw 207 (M4) and is not designed to bear the weight of the whole unit.

~ The system is best handled/lifted using the pendulum arm and the casting 220 at the base of the windvane shaft.

foto  
flansch Pl  
only

Abb

### 3.0 CAUTION

~ The WINDPILOT PACIFIC LIGHT is a servo-dynamic system.

~ Keep hands well away from the pendulum arm when the system is in operation (trap hazard).

~ Take care when adjusting the windvane shaft manually (e.g. changing course) while the vane is in operation: moving parts can be dangerous.

~ The pendulum rudder can only be raised into the lift-up position at boat speeds of less than 2 knots.

~ The pendulum rudder may be dropped back into the operating position at any time.

~ Always secure the system with a safety line before attempting to fit or remove it.

~ Check the mounting nuts and bolts on the transom regularly.

~ CAUTION: the system may be lost if the mounting bolts work loose. Never use the system if the bolts are known to be loose.

~ When fitting or removing the system handle/lift it only using the pendulum arm and the casting at the bottom of the windvane shaft!

~ The PACIFIC LIGHT is designed for boats no larger than 27 ft / 2.5 metric tons.

Abb PL nur  
für schiffe  
bis

### 4.0 MAINTENANCE

~ The system is largely maintenance free. It is, however, as susceptible to the effects of sun, salt and dirt as anything else onboard and will reward you for a little attention. Please take note of the care guidelines below. Follow them, and your WINDPILOT system should keep going indefinitely.

#### 4.1 BEARINGS

~ The bearings are made from Teflon, POM and Delrin. These materials must not be oiled or greased.

pikto-  
gramm  
no öl



~ Grease or oil in contact with seawater quickly solidifies, causing bearings to stick or seize.

#### 4.2 CLEANING

~ Clean the system with fresh water and rinse thoroughly.

pikto-  
gramm  
wasser-  
schlauch

~ TIP: thoroughly soak your PACIFIC LIGHT in salt water (15 minutes should be long enough) at twilight on a damp evening and then rinse with fresh water.

~ This applies equally to the rest of the boat. Salt crystals and sunlight soon take the gloss off any shiny surface, but a thorough soak and rinse at the end of every long trip will keep your boat looking its best.

#### 4.3 BEVEL GEAR LINKAGE

abb  
kegelrad

~ Clean the bevel gear linkage twice a year.

~ Clean any salt or oil from bearing 328.

~ Make sure the gears are in the right position when reassembling the linkage (see Troubleshooting section).

~ Never grease bearing 328!

~ Axle 303 may be treated with WD-40 or Teflon spray.

~ TIP: try to avoid leaving your system exposed for long periods without use (remove or cover the system). When the pendulum rudder is in the lift-up position, dew and rain wash accumulated dirt and grime off the rudder and rudder shaft down into the bearings, causing them to seize. The bearings can only become blocked with salt/dirt in the lift-up position; the same can never happen in the operating position!

#### REMOVING THE SMALL BEVEL GEAR 305

abb kl  
kegelrad

~ Remove red cap 320.

~ Release screw 163 to remove push rod 150.

~ Release screw 334.

~ Remove bevel gear and clean.

~ Apply Loctite to the screws during reassembly.

#### 4.4 PUSH ROD

abb kardan  
oben unten

~ Always check that the top (156) and bottom (160) universal joints turn smoothly on the push rod 150. If they stick at all, try loosening the connections. Apply WD-40.

#### PUSH ROD POSITION

~ Nuts 154 are adjustable.

~ Ideal position: windvane vertical, pendulum arm 300 vertical, pendulum rudder 440 in line with keel, arm of small bevel gear 305 in the 'quarter past twelve' position.

#### 4.5 CAST AND TUBULAR COMPONENTS

~ All the cast and tubular components in the system have been treated with lanolin before assembly and will come apart again readily even after prolonged operation.

~ Wax the tubular components occasionally.

#### 4.6 LANOLIN

abb ~ Lanolin has been applied to all screwed or bolted joints to prevent electrolytic  
topf auf ~ reactions.  
dem lanolin ~  
drauf steht ~ Lanolin works equally well on all the other screws and bolts on the boat (and also  
makes a good hand creme!).

#### 4.7 ANTIFOULING

abb ~ Never antifoul the pendulum rudder blade. It should only be in the water when the  
topf auf ~ system is in use, so there should never be any growth on it anyway.  
dem antif. ~  
steht dick ~ The pendulum rudder blade can be cleaned in the lift-up position.  
durch-gestr- ~  
ichen ~ Antifouling may clog the bearing if liquid paint runs up the blade in the lift-up  
position.  
~ TIP: treat the blade with varnish only.

#### 4.8 WINDVANE

abb wind- ~ A spare or replacement windvane must weigh exactly the same as the original  
fahne auf ~ windvane. If it does not, adjust the dimensions until it does.  
der waage ~ CAUTION: even a coat of paint can significantly add to the weight of your  
windvane. The painted windvane must weigh exactly the same as the original it is  
to replace.  
~ The counterweight is matched to the weight of the original windvane. Using a  
windvane of a different weight will reduce the sensitivity of the system and  
impair steering quality, especially in lighter airs.  
~ The windvane may be no more than 50 g/1¾ oz lighter than the counterweight. It  
must never be heavier than the counterweight!

#### 4.9 WINDVANE TELLTALE

foto buch ~ There comes a point where there is just too little wind to move the windvane. The  
fluttering of the windvane telltale, a strip of spinnaker cloth attached towards the  
upper trailing edge of the vane, provides that little extra steering impulse and  
extends the range of conditions over which the system can sensibly be used.

### 5.0 TROUBLESHOOTING

#### 5.1 SYSTEM IS TURNING THE WRONG WAY

foto ~ The steering lines are connected wrongly to the wheel adaptor. See 1.6.8.2  
leinen- ~  
verbin-dung ~ Rigging the Steering lines.

#### 5.2 SYSTEM PERFORMANCE IS NOT SATISFACTORY

abb ruder- ~ Is the pendulum rudder positioned correctly? See 1.7 The Pendulum Rudder.  
position ~ Alternatively, is the...

##### 5.2.1 POSITION OF PENDULUM RUDDER BLADE

~ If the pendulum rudder blade is too far aft, the balance proportion will be too  
small and the system will only be able to steer at relatively low speeds. No  
effective steering impulse will be generated at higher speeds.

~ If the pendulum rudder blade is too far forward, the balance proportion will be too  
large. The pendulum rudder will be moving the windvane instead of the other way  
around, leaving the system completely unable to steer.

~ Lower the pendulum arm into the water. If it immediately starts swinging around and seems unable to settle on centre, the pendulum rudder is too far forward.

### 5.2.2 STEERING LINES RIGGED INCORRECTLY

abb vogel-  
perspek-tive-

~ Are the transmission angles ok? See 1.6 The Steering Lines.

~ Do you need a crossbar? See 1.6 The Steering Lines.

~ Are the steering lines free of slack, stretch and play? See 1.6 The Steering Lines.

### 5.2.3 THE PENDULUM RUDDER IS NOT MOVING 25 DEGREES TO EACH SIDE

~ See 2.2.6.1 Is the Variable Force Transmission Set Correctly?

## 5.3 SYSTEM IS STICKING

### 5.3.1 AT THE WINDVANE

abb

~ Does the windvane hanger 110 turn easily on axle 113?

~ Check screw connection 113/116 and adjust if required.

abb

~ Are the screw connections on the push rod 150 and the top and bottom universal joints 156/160 properly adjusted? The universal joints must turn freely on the push rod.

abb

~ The upper screw 301 on the pendulum arm 330 must not be too tight otherwise bearing 328 will stick.

### 5.3.2 AT THE WINDVANE SHAFT

abb  
mit sich-  
erungs-  
schraube  
206

~ If the windvane shaft will not turn easily (for course adjustment) even when adjustment lever 205 is released, remove locking screw 206/207 and raise the windvane shaft.

~ Apply WD-40 or Teflon spray and reassemble, taking care to ensure that bearing 141/142 is properly positioned.

~ Tighten locking screw 206/207 until it stops and then loosen it slightly so that the windvane shaft can turn freely. Screw 207 serves merely to hold the shaft in place if the unit is lifted; it should not be pressed hard against shaft 140.

### 5.3.3 AT THE RUDDER AXLE

~ If there is friction at the rudder axle, the system will have to be disassembled and cleaned.

abb kegel-  
radge-triebe  
mit schaft

#### 5.3.3.1 DISASSEMBLY PROCEDURE

~ Remove the system from the transom.

~ Remove red cap 320.

~ Remove screw 327.

~ Push shaft 255 down out of bevel gear 325.

abb

~ Mark the relative positions of the two gears in the bevel gear linkage.

~ Clean bearing 328.

#### 5.3.3.2 ASSEMBLY PROCEDURE

~ Check the position of the two gears. The lever on the small gear 305 should be in the 'quarter past twelve' position.

- ~ Check that the pendulum arm is vertical.
- ~ Check that the pendulum rudder blade is in line with the keel.
- ~ Check that the hole in bevel gear 325 is flush with the hole in shaft axle 327.

#### 5.3.4 AT THE STEERING LINES

- ~ Do the blocks move freely?
- ~ Are the transmission paths too long?
- ~ Is the wheel too far from the transom (centre cockpit)?
- ~ Are the main rudder bearings stiff?
- ~ Is the wheel steering system stiff?

#### 5.4 THE PUSH ROD IS BENT

- ~ Check the balance proportion of pendulum rudder blade 440 (see 1.7 The Pendulum Rudder).
- ~ The push rod can be straightened easily.

#### 5.5 THE WINDVANE SHAFT IS LOOSE

- abb ~ Tighten bolts 311 and ...

#### 5.6 THE RUDDER BLADE IS VIBRATING

- abb ~ Adjust the position of the pendulum rudder blade 440 in rudder fork 430.
- ~ The vibrations should die down if you move the rudder blade aft very slightly.
- ~ CAUTION: do not overtighten bolt 435 (overload protection).

#### 6.0 REPAIRS

- ~ The system may be disassembled and reassembled using the component drawings.

~ If cast components suffer collision damage and replacements cannot easily be obtained, it may be possible to repair them. Cast aluminium components can be welded back together quite easily if the faces to be joined are first heated thoroughly for a few minutes with an open welding torch flame. The actual welding procedure should only be attempted with proper aluminium welding equipment.

~ 6 mm marine plywood is ideal for making replacement windvanes (see “Adjusting the Windvane for Different Wind Strengths” in the Sailing with Your WINDPILOT section).

~ The pendulum rudder blade may be replaced with a simple wooden plank (approx. 120 x 900 x 20 mm). Even a completely unprofiled piece of wood will work on a temporary basis.

~ CAUTION: the pendulum rudder needs a balance proportion of around 20%, which means that 20% of the rudder area must be located in front of the rudder shaft. If necessary try turning the blade around. The windvane should always control the pendulum rudder blade and not the other way around. Check this by lowering the pendulum arm 300 into the water. If it immediately swings out to one side and forces the windvane to do the same, there is too much rudder blade in front of the shaft.

~ Some bearing play may develop in pendulum axle bolt 310. This is not a problem and will not impair the steering performance of the system.

If you have any questions, please do not hesitate to contact us at

Headquarters

Europe/worldwide

tel. ++49 40 6525244

fax ++49 40 68 65 15

e-mail [windpilot@t-online.de](mailto:windpilot@t-online.de)

[www.windpilot.com](http://www.windpilot.com)

in the US

tel. +1 727 319 8017

fax +1 727 398 6288

e-mail [windpilot@compuserve.com](mailto:windpilot@compuserve.com)

and we'll do everything we can to help!